

# Installation Instructions

## Striped Rubber Wheelstop

### Tools & Hardware Required

One ½" x 14" rebar for each hole in the wheelstop  
High-speed hammer drill with ¾" masonry bit  
Sledge hammer for driving rebar

### Step 1

Position the wheelstop in its installation position and, using its pre-drilled holes as templates, mark the location of each hole on the parking surface.

### Step 2

Remove the wheelstop. Using a high-speed hammer drill with a ¾" masonry bit, drill a hole at each marked location to avoid fracturing the asphalt with the rebar.

### Step 3

Reposition the wheelstop in its installation position. Drive the rebar through the wheelstop and into the drilled hole until the spike is snug against the counter-bored surface of the wheelstop's pre-drilled hole. Repeat for each hole in the wheelstop.

DO NOT DRIVE BEYOND SNUG. If driven too far rebar may damage the wheelstop and void the product warranty.