

BC1465 BC1470 BC1481 BC1482 BC1485 BC1490 BC1501 BC1502 BC1505 BC1510 BC1550






2/5

FOR ASSEMBLY


STEP 1 Seat Assembly

- Stand two outer bench ends (A) upright Lay a plastic board (B) over the bench ends (A) closest to the end Align the holes in the plastic board with the predrilled holes in the bench ends ٠
- Secure the board with the $\#10 \times 2.5$ " screws (C) .
- Repeat for each plastic board starting at the front seat board and working toward the back ٠





STEP 2 Seat Assembly

- Move the remaining bench end (A) to the center • of the bench
- Align the predrilled holes in the bench end with •
- holes in the plastic board (B) Secure each plastic board to the bench end with #10 x 2.5" screws (C)



- STEP 3 Backrest Assembly
 Hold a plastic board (B) up to the back rest portion of the bench end (A)
 Align the predrilled holes in the bench end (A) with holes in the plastic board (B)
 Secure each plastic board to the bench end with #10 x 2.5" screws (C)
 Square all components and tighten all screws





ALL DIMENSIONS ARE SHOWN IN INCHES

HARDWARE: Stainless Steel